

Termination Kits for Chromalox SRR Type Cables.

The SRR Termination Kit contains the following items.

1. End Cap (small block with hole for cable)
2. Tube of adhesive.
3. Three insulated crimp lugs.
4. Length of heat-shrink tube.
5. Length of three-core electrical cable.

Method of Use

1. Cut the SRR heater cable across at a slight angle.
2. Apply a small amount of adhesive into the end cap.
3. Insert the heater cable and allow sealing.
4. Bare back a short length of the heater cable cores at the other end of the cable.
5. If you wish to earth the cable twist the braiding into a small "pigtail".
6. Bare-back the cores of the electrical cable (including the green if you wish to earth).
7. Insert the cores into the insulated crimp-lugs with the green matching the "pigtail" of the heater cable.
8. Crimp the lugs tightly.
9. Cover the crimped section with the heat-shrink tube and shrink to a neat fit.
10. Connect the electrical cable as required to power.